

# Instructions for assembling 19301 Kitchen Compact Trolley

## Step 1

Hammer dowels into the holes in each leg. Fix each leg to the base of the frame using 4 Allen key screws provided.




## Step 2

Fix castors to the base frame using the small screws provided. Fix the trolley top to the legs using 4 Allen key screws provided.

## Step 3

Fix drawer sides to drawer back using 4 drawer screws. Slide the drawer base into groove, then position drawer front onto assembly and secure with 4 small screws. Repeat for second drawer.



## Step 4

Add drawers, shelves and wine rack.

Your Kitchen Compact Trolley is now complete.

# ASSEMBLAGE DE LA TABLE 19301 TABLE ROULANTE CUISINE

1

Fixez les gouges dans les trous de Chaque section verticale.  
Fixez chaque section verticale à la base en utilisant les 4 vis Allen fournies.




2



Vissez les roues à la base.  
Fixez le dessus de la table aux sections verticales à l'aide de 4 vis allen

3



4



Placez les tiroirs, étagères et porte-bouteilles.  
Vous pouvez maintenant profiter de votre Table roulante "Cuisine Compacte"